



Aba Daba Rents

4351 Auburn Blvd.
Sacramento, CA 95841-4152
(916) 484-7368 Fax (916) 482-2552
www.abadaba.com

TRIMMER SAFETY

Read and Understand All Instructions and Warnings Before Operating This Trimmer.

WARNINGS

The HONDA Trimmer is Four--Cycle and requires GAS fuel.

This item contains one or more chemical known to the state of California to cause cancer, birth defects or other protective harm.

IMPORTANT SAFETY INFORMATION

These trimmers are designed to cut grass and weeds. Other uses can result in injury to the operator or damage to the trimmer and other property. These trimmers are intended for use by hardening professionals. Never allow children to operate the trimmer. **Always Wear Eye Protection and Protective Clothing.** The most frequent injuries associated with string trimmers are eye injuries caused by thrown debris. Always wear safety glasses or goggles that meet the ANSI Z87.1 rating whenever you use the trimmer. The operators must wear hearing protectors when using this trimmer. Hearing protectors will protect the operator's ears from noise damage. Wearing protective clothing also reduces the risk and severity of injury from thrown debris or contact with the cutting attachments. Wear the trimmer harness, gloves, a long-sleeved shirt, long pants, and sturdy boots with non-slip soles.

Keep Away From Cutting Lines and Blades. A spinning cutting attachment can cut through your clothes and skin just as easily as it cuts through grass and weeds. Keep all parts of your body away from spinning cutting attachment. Even after the engine has stopped, the cutting attachment will spin for several seconds. Do not touch it until it has stopped spinning, or you may get cut.

Turn the Engine Off When Not Trimming or Refueling. If you stop trimming or cutting for any reason, even to clean off the cutting attachment, always shut off the engine. Never refuel while unit is running and/or hot.

Keep People Away from Your Working Area. To prevent injury to others, keep the trimmer away from your body, lowering your chances of being cut by the trimmer's blade or cutting line.

Clear the Working Area First. Objects thrown by trimmer can cause serious injury. Before operating the trimmer, carefully inspect the area, and remove all broken glass, pieces of wire, and other loose objects.

Keep the Trimmer Properly Maintained. Do not operate the trimmer without a debris shield properly installed. Make sure you have the right shield installed for your cutting attachment.